BOXwise®

Factory Defaults

$+$*

If you are not entirely sure if the scanner is set to factory defaults please first scan the barcode above.

This sheet will put the scanner in a general configuration applicable for most BOXwise customers. However, the settings below might not be applicable to your situation. If you are in doubt, please contact trancon support.

Enter configuration

$+

Set Radio Address

RA0RF

0	3	6
1	4	7
2	5	8
		9

Please scan four digits to set the radio address. Choose a combination other than 0000.

Exit configuration

$-

Bind (place in cradle within 10 seconds after scan)

$+RN0$-

Set cradle in RS-232 Mode

$+CP0$-

trancon.